



NOTES

1. Conduit to be positioned to minimize the likely hood of damage from on-coming traffic and sidewalk snow clearing equipment.
Install PVC conduit system to obtain a neat and straight installation and leaving adequate climbing space on wood poles.
 2. On concrete poles mount conduits using 16mm stainless steel strapping and buckles.
On wood poles mount conduits using PVC coated steel or galvanized pipe straps with 6 x 38 mm lag bolts.
Install strapping every 1.0 m, unless otherwise specified.
 3. Handwell may be required for distances greater than 3.0 m, unless otherwise specified.
 4. For orientation and location of poles and equipment refer to layout drawings.
- All dimensions are in millimetres or metres unless otherwise shown.