



**GENERAL ARRANGEMENT**

**NOTES**

1. Drill 25 mm dia. aperture at lower bracket location. Install rubber grommet.
  2. For offset distances, ramp and shoulder widths, refer to layout drawings.
  3. All field cuts, threads and holes to be de-burred and touched up with zinc-rich paint.
- Dimensions are in millimetres or metres, unless otherwise shown.