



NOTES

- ① THE "NO WORK AREA" IS NOT TO BE ENCROACHED UPON IN ANY WAY.
- ② ALL TREE ROOTS WITHIN THE "HAND DIG ZONE" WILL BE CAREFULLY LOCATED AND CLEANLY PRUNED WITH A HAND PRUNING SAW TO THE DEPTH REQUIRED FOR CONSTRUCTION
- ③ WORK IN THE "OPEN WORK ZONE" IS SUBJECT TO NORMAL CONSTRUCTION PRACTICE.

**METRIC**  
ALL DIMENSIONS SHOWN HERE ARE IN  
MILLIMETERS UNLESS OTHERWISE NOTED

APPROVED BY

*Tom Denes*  
TOM DENES, P. ENG.  
EXECUTIVE DIRECTOR TECHNICAL SERVICES

SCALE

N.T.S.

DATE: JUNE, 2001

REVISED:

STANDARD No.

T-220.01