



NOTES:

1. WHEN THE UNSUPPORTED BEAM EXCEEDS 3600 mm IN LENGTH, BRACED VERTICAL SUPPORTS WITH PROPER FOOTING WILL HAVE TO BE INSTALLED. SIZE OF FOOTING IS DEPENDANT ON SOIL CONDITION.
2. WHEN SHORING IS LEFT IN SEWER TRENCH, THE CONTRACTOR SHALL MAKE SURE THAT PROPER OPENINGS ARE LEFT IN THE SHORING AT THE WATER SERVICE CROSSING.

All dimensions are in millimetres unless otherwise shown.



ENGINEERING AND CONSTRUCTION SERVICES STANDARD DRAWING

REV 1

APR 2013

TYPICAL DETAILS FOR SUPPORTING
WATER PIPE 32 mm AND SMALLER

T-1007.01-3

NTS

SHEET 1