



NOTES

1. The #6 AWG pole system ground shall not connect to the grid of the service ground.
2. The #6 AWG traffic controller cabinet ground shall not be bonded to any ground system, except at the ground bus of the service cabinet.
3. Two (2) ground plates can be used in lieu of Three (3) ground rods.