



SECTION THROUGH TYPICAL MAINTENANCE HOLE

DETAIL "1" BRACKET ASSEMBLY

NOTES:

NUMBER OF BRACKET ASSEMBLIES WILL DEPEND ON LENGTH OF DROP PIPE.

All dimensions are in millimetres unless otherwise shown.



ENGINEERING AND CONSTRUCTION SERVICES STANDARD DRAWING

REV 2

APR 2014

INTERNAL DROP PIPE
FOR MAINTENANCE HOLES

T-1003.01-2

NTS

SHEET 1