


SECTION THROUGH TYPICAL MAINTENANCE HOLE

DETAIL "1" BRACKET ASSEMBLY

NOTES:

1. NUMBER OF BRACKET ASSEMBLIES WILL DEPEND ON LENGTH OF DROP PIPE.
2. INTERNAL DROP PIPES ARE NOT PERMITTED IN A TRUNK SEWER MAINTENANCE HOLE.

All dimensions are in millimetres unless otherwise shown.

	ENGINEERING AND CONSTRUCTION SERVICES STANDARD DRAWING	REV 3	SEP 2019
	INTERNAL DROP PIPE FOR MAINTENANCE HOLES		T-1003.01-2
		NTS	SHEET 1