

Calibrating Your Thermometer

1. Fill a medium-sized glass with ice. Add water to ice. Place thermometer in glass of ice water.
2. Wait 3 minutes. Stir water occasionally.
3. After 3 minutes, thermometer should read 0°C (32°F)
4. If not, leave probe in ice water
5. Using pliers or a small wrench, turn the adjustable nut on the back of the thermometer head until the needle reaches 0°C (32°F). You may need to add more ice.
6. Wait 3 minutes. Stir occasionally. Readjust the nut if required for the needle to read 0°C (32°F)